


- FIG 1 → 1. Place the Gas Pump Helper between the gas pump handle.



← FIG. 1

2. The Gas Pump Helper hold the gas pump trigger in the on-position.

3. The magnet on the back of the Gas Pump Helper keep it secure inside the gas tank cover.



← FIG. 2

H.m.S. Products

FIG 3.

